

NOVIKSTONE DRY STACK  
NOVIK

# NovikStone DS Dry Stack Stone

SKU: NOVIK-DS

**WEIGHT**

1.9 lbs (0.9 kg) per panel

**WARRANTY**

Lifetime Limited Warranty

**COLOURS**

8 available

**PROFILES**

DS — Dry Stack Stone

NovikStone DS delivers the clean, modern drama of dry-stacked fieldstone — no mortar, no masonry tools, no maintenance. Random panel lengths and split-face textures create an authentic stone appearance on any wall, while moisture-impervious polypropylene construction ensures durability from grade level to the roofline. Available in 8 rich stone colours and installable both horizontally and vertically, NovikStone DS is certified under CCMC 13420-R, ICC-ES, and TDI, and backed by a Lifetime Limited Warranty.

## Key Features

- Authentic mortarless dry stack look — random lengths and split faces
- Professional grade — light enough for one-person installation in a fraction of the time
- Impervious to moisture — can be installed at ground level or at the roofline
- Complements all types of siding
- Requires little to no maintenance
- Lifetime Limited Warranty
- No mortar, adhesives, or masonry tools required
- Seamless joints — attractive visual appearance
- Can be installed horizontally or vertically (interior accent feature walls)
- Durable — resistant to warping, cracking, expansion, and contraction
- CCMC 13420-R / ICC-ES / TDI approved

## Available Colours

STONE

8 colours



Anthracite



Onyx



Lava



Brownstone



Flint



Limestone



Basalt



Travertine

## Profiles & Specifications

DS

Dry Stack Stone

Make a strong visual impression. Anywhere. The mortarless look of assembled stone in random lengths and split faces are strategically placed to bring an authentic, organic look to any wall. It all comes together in Dry Stack — NovikStone's flagship stone panel that delivers the modern, clean aesthetic of dry-stacked fieldstone with the durability and low maintenance of polypropylene.



Length	31.9" exp. / 41.5" full (81 cm / 105.41 cm) per panel
Height / Width	11.4" exp. / 13.13" full (28.9 cm / 33.34 cm) per panel
Panel Weight	1.9 lbs (0.9 kg) per panel
Panels / Box	10 pcs/box
Coverage	Approx. 1/4 sq. (approx. 25 sq. ft. / 2.32 m <sup>2</sup> ) per box
Installation	Horizontal or Vertical — full facade, accent zones, interior feature walls

\* Corner (2-in-1 Multifunctional): 4.3" x 15.1" exp. / 5.9" x 16" full (10.8 cm x 38.4 cm exp. — 14.9 cm x 40.6 cm full) | 5 corners per box | 1 corner assembly = 15.1" (38.35 cm) linear coverage. No mortar, adhesives, or masonry tools required.

## Certifications & Testing Standards

NovikStone DS Dry Stack Stone meets or exceeds the following Canadian and international performance standards.

- CCMC 13420-R — National Research Council of Canada
- ICC-ES Evaluation Report — International Code Council Evaluation Service
- TDI Approvals — Texas Department of Insurance wind resistance
- MasterFormat 07 46 33.04 — Polypropylene Siding classification
- Lifetime Limited Warranty

## Compatible Accessories

### 2-in-1 Multifunctional Corner

4.3" x 15.1" exp. / 5.9" x 16" full — 5 pcs/box | 1 assembly = 15.1" (38.35 cm) linear coverage  
Versatile 2-in-1 corner piece that forms both inside and outside corners. Join two sections together to create one corner assembly with 15.1" (38.35 cm) linear coverage. Exposed: 4.3" x 15.1" | Full: 5.9" x 16" | 5 corners per box. Install corners before starter strips. If installed at base of wall, butt bottom of corner assembly against floor.

### Universal Starter Strip

72.6" (184.5 cm) x 0.9" (2.4 cm) — 24 pcs/box  
Required for all NovikStone installations. Sets the first row of panels at the correct angle and ensures a level, uniform installation from the base row up. Nail through center hole and all nailing holes at maximum 8" (20.32 cm) intervals. If at floor level, leave 1-13/16" (4.61 cm) gap between starter and floor.

### NovikTrim J-Channel

72" (182.9 cm) x 1.3" (3.2 cm) — 20 pcs/box  
Used around windows, doors, and all perimeter edges. Leave 1/4" (0.64 cm) gap between the trim and siding panel end. Required opening for finishing trim: 1-1/8" (2.86 cm). Available in matching colours. Also sold individually.

### NovikLedge

Panel: 30.1" x 2.5" x 2.6" (76.5 x 6.4 x 6.7 cm) | Corner: 5" x 5" x 2.6" (12.7 x 12.7 x 6.7 cm) — 4 pcs/box

Premium ledge accent for windowsills, door surrounds, and architectural details. Available in Gray Mortar, Weathered Blend, and Onyx. Panel: 30.1" (76.5 cm) x Depth 2.5" (6.4 cm) x Height 2.6" (6.7 cm) | Corner: 5" (12.7 cm) x Depth 5" (12.7 cm) x Height 2.6" (6.7 cm) | 4 pcs/box. Items also sold individually.

## Installation Guide

- 1 Preparation: install at the lowest point of the structure, working left to right. Always install decorative corners before starter strips where corners are required. Install Universal Starter Strips at the lowest point — ensure the horizontal starting line is perfectly level and square with the wall. Leave a 1/2" (1.27 cm) gap at each wall end when using NovikTrim1. If the lowest installation point is at floor level, leave a 1-13/16" (4.61 cm) gap between the starter strip and the floor. Nail starter strips through the center hole and all nailing holes at maximum 8" (20.32 cm) intervals. Slide successive starter strips into each other leftward to the stopper.
- 2 Fastener requirements: use non-corrosive (aluminum or galvanized) nails or screws with a head diameter of minimum 0.4" (1 cm) and a shank diameter of 0.150" (0.38 cm). Fasteners must penetrate a minimum of 1-1/4" (3.18 cm) into a solid surface. For furring walls: install furring strips at 8" (20.32 cm) o.c. vertically with one strip behind each nail hole.
- 3 Nailing each panel: nail the center hole first, then both extremities, then the lateral holes. Ensure a minimum of 5 nails in the nailing channel at maximum 16" (40.64 cm) intervals. Never hammer nails flush — leave a 1/16" (0.16 cm) gap. The stoppers around the holes stop the hammer automatically and provide the required clearance.
- 4 Panel assembly: cut the left side of the first panel in a clean, straight line — this cut is visible. Insert the panel onto the starter strip using the hooks on the back and slide up to the corner trim. No gap is required between the panel and corners. Hook successive panels onto the starter strip and slide into the previous panel; lock tabs on both sides — butt panels tight, no gap needed between panels. Measure the wall length before starting to avoid a very small piece at the right end. For a better appearance, cut panels against corners at a 3° angle.
- 5 Row stagger: start the second row with a 16" (40.64 cm) offset from the cut line of the first row. Slide the bottom of the panel into the continuous slot on top of the previously installed row. Alternate the offset position on each new row to create an authentic random-stone appearance. Check horizontal alignment every few rows.
- 6 Last row / cut panels without nail holes: choose a concealed spot and use a knife to create new 1/2" (1.27 cm) slots — slots must be wider than the nail shank but narrower than the nail head. This allows thermal expansion and contraction movement. Nail at maximum 16" intervals. If straightening is needed, add shims behind the new nailing slots.
- 7 Trim finishing: leave a 1/4" (0.64 cm) gap between any trim (NovikTrim1 or J-Channel) and the siding panel end. The required opening for finishing trim is 1-1/8" (2.86 cm). For a cleaner base finish, install NovikTrim1 at wall base with starter strips 2-1/4" (5.72 cm) from base and NovikTrim1 Base 3/16" (0.48 cm) from base.
- 8 Vertical installation (indoor/accent): install left to right from the highest point downward. Install decorative corners first, then starter strips vertically at the right side of corners. Leave 1-13/16" gap between corners and starter strips. Nail panels as in standard installation. Each successive row offsets 16" from the previous row's cut line.
- 9 Heat sources: when installing near a heat source such as a fireplace or electric baseboard heater, the installer is responsible for ensuring panels will not exceed 176°F (80°C). Maintain safe clearance distances.
- 10 Care & maintenance: NovikStone DS requires no painting, staining, caulking, or masonry maintenance. Clean periodically with mild soap and water using a soft-bristle brush — clean bottom-up and rinse top-down with clear water. Do not use a pressure washer, abrasive cleaners, or strong solvents.



# NOVIK

## Ready to order?

Submit your spec list and we'll respond with pricing and availability - usually within one business day.

**WEB**

[promaterials.ca](http://promaterials.ca)

**PHONE**

(905) 836-7272

**EMAIL**

[info@promaterials.ca](mailto:info@promaterials.ca)

**ADDRESS**

Unit 5, 1235 Journey's End Cir, Newmarket, ON